
DETAILED MEASUREMENTS

FRENCH BALCONY RETRO WITH POSTS
STANDARD HEIGHT INTERMEDIARY RAIL AND CROSSBARS MADE OF




- A Post c/c-measurements
- B The spacing between the vertical bars depends on the c/c dimensions of the posts
- C Total railing height 1000 / 1100 mm
- D 145 mm measured from the floor surface



^{*} When attaching to brick or concrete, fasten the vertical support at least 50 mm, and ideally 75 mm, from the wall edge.

DETAILED MEASUREMENTS

FRENCH BALCONY RETRO WITH POSTS
STANDARD HEIGHT INTERMEDIARY RAIL AND CROSSBARS MADE OF




- A Post c/c-measurements
- B The spacing between the vertical bars depends on the c/c dimensions of the posts
- C Total railing height 1000 / 1100 mm
- D 145 mm



^{*} When attaching to brick or concrete, fasten the vertical support at least 50 mm, and ideally 75 mm, from the wall edge.

DETAILED MEASUREMENTS

FRENCH BALCONY RETRO WITH POSTS STANDARD HEIGHT INTERMEDIARY



- A Post c/c-measurements
- B The spacing between the vertical bars depends on the c/c dimensions of the posts
- C Total railing height 1000 / 1100 mm
- D 145 mm



^{*} When attaching to brick or concrete, fasten the vertical support at least 50 mm, and ideally 75 mm, from the wall edge.